

IGBT K SERIES – QUICK START

Primary Parameter Setting Guidelines

Page Number :

Pg. 1) Index Page

Pg. 2 - 3) Introduction to Compact IGBT Inverter

Pg. 4 - 7) List of Error Code and Diagnosis

Version : 2-1909

Page 8) **Please Un-LOCK your inverter 1st before you can make any chance to the parameter**



9) Switching Method between Various Mode of Inverter (No Password Protected)

10) How to display current ampere of the running motor

11) How to adjust the running frequency via KNOB / UP-DOWN button on operation panel.

12) How to enable to knob function (i.e. to adjust speed via Knob rotation)

13) How to set Maximum and Minimum Output Frequency

14) How to adjust Acceleration Time and Deceleration Time

15) How to change rotation direction - Forward / Reverse

16) How to display Motor RPM instead of Frequency on display screen

17) How to display Machine Speed (output speed) instead of Frequency on display screen

18) How to adjust Thermal Current Protection (TCP - overload protection for your drive/motor)

19) How to change the Switching Frequency of the inverter (PWM Carrier Frequency)

20) How to use external speed potentiometer (VR) to adjust running frequency

21) How to use 2-way External Selector Switch for : Run / Stop operation

22) How to use 3-way External Selector Switch for : Reverse / Stop / Forward operation

23) How to start 1phase inverter run automatically when power is switch on (with 2-way Selector Switch)

24) How to setup Emergency Stop Button

25-26) How to use Sensor to stop operation by using Multispeed Setting

(Motor rotation is stopped in shorter time compared to Coast to Stop function)

27-28) How to use run Forward and Reverse direction with different speed.

29) How to duplicate parameter Between different inverter (Remote keypad required).

30) How to use "SPEC" button on operation panel to run at 2nd Speed (Multi-speed Level 2 command)

31) How to give alarm signal to PLC via Relay

32) How to restore parameter to original Factory Setting

33) How to use Momentary Switch to adjust running frequency (Up/Down)

34) How to use Momentary Switch to adjust running frequency (Up/Down), and Momentary Switch to Clean Up/Down Frequency Command

35) Product and Mounting Dimension of the Inverter and Remote Keypad



Portable Keypad
With Modbus (RS485)
Communication.



COMPACT INVERTER

IGBT SERIES

1 PHASE INVERTER WITH 150% OVERLOAD PROTECTION



The compact IGBT inverter is especially advantageous for standard application by virtue of its user friendliness. It offers simple and safe operability, energy saving, compact design as well as superior performance. The inverter is use in numerous application such as conveyor drives, feeders, machining tool and door drives. It is compactible with Unit Type AC Speed Controller (US series).

MODEL NO	IGBT – K060	IGBT - K100	IGBT - K200
Motor Rating (maximum)	Up to 60W	Up to 120W (1/6 HP)	Up to 200W (1/4 HP)
Rated Output Capacity	0.2kVA	0.4kVA	0.6kVA
Rated Output Current	0.6 Amp	1 Amp	1.5 Amp
Rated Output Voltage	AC 3 Phase 220V (3Ø220V)	AC 3 Phase 220V (3Ø220V)	
Range of Output Frequency	0.1Hz ~ 400Hz	0.1Hz ~ 400Hz	
Power Source Voltage	AC 1 Phase 200V~240V (1Ø), 50Hz/60Hz	AC 1 Phase 200V~240V (1Ø), 50Hz/60Hz	
Input Current	1.2 Amp	2 Amp	3 Amp
Permissible AC Power Source Fluctuation	200V ~ 240V, 50Hz/60Hz, ± 5%		200V ~ 240V, 50Hz/60Hz, ± 5%
Overload Protection	120% of rated output current for 1 minute	150% of rated output current for 1 minute	
Cooling Method	Self-cooling	Self-cooling	
Protection Level	IP20		
Dimension	Body 52 x 127 x 60mm • Mounting Frame: 60 x 100 x 3mm		
Weight	0.38KG	0.4KG+	
Options	NIL	With Braking Transistor / Without Braking Transistor	
Remark	Product dimension and mounting compatible with US Type Speed Controller (USM71-USM72 / US71-US72)		

OPERATION PANEL

Function Key

	Start
	Stop • Reset
	Up • Down
	Enter or Exit the Function Mode
	Set • Switch Monitor Mode
	Switch Function • Group • Number
	Special Function Key

- Status Display I**
Indicator : Frequency • Voltage • Current • Operation
- Status Display II**
Power Indicator • SPEC • START Key Indicator
- Main LED Display (high brightness)**
Display of Setting & Error Code
- Potentiometer / Knob**
Fast Setting and Input

Note: The contents of this data sheet are subject to change without prior notice for the purpose of continuous product improvement. Comprehensive Product Manual of the Inverter available upon request.



COMPACT INVERTER

IGBT SERIES

**1 PHASE INVERTER
WITH 150% OVERLOAD PROTECTION**



LDS Compact Motor Ampere


Function	Description	Initial Factory Setting (TW)	LDS Setting (MY-SG-TH) ★
F0.01	Parameter Lock (Changeable/Lock)	0	0 (Un-Lock) 1 (Lock)
F0.18	Parameter List (Simple/Complete)	0 (Simple)	1 (Complete)
F0.20	Default Setting (Taiwan / Malaysia)	dF60	dF50
F1.21	Switching Frequency	2	4
F2.16	Jog Speed	6.0Hz	0.0Hz
F2.18	Acceleration Time	5.0s	2.0s
F2.19	Deceleration Time	5.0s	2.0s
F2.32	Maximum Output Frequency	50.0Hz	60.0Hz
F2.48	Minimum Output Frequency	0.0Hz	0.0Hz
F4.07	Overload Protection (Independent)	1	2
F4.08	Overload Protection Setting - Motor's Rated Ampere	0.3A ~ 1.5A Based on Motor Spec	
F4.10	OVLP Tripped Time	0.5 (30s)	0.5 (30s)
F5.08	Analogue Frequency Dead Band	0.00	0.05
F5.19	X1 Terminal	22	22 (Forward)
F5.20	X2 Terminal	23	23 (Reverse)
F5.21	X3 Terminal	10	1 (Jog Speed)
F5.25	Digital Response Time	10	3

Motor Power	Rated Ampere	F4.08 Setting
25W	0.23	0.3
40W	0.36	0.4
60W	0.50	0.6
90W	0.65	0.7
120W	0.75	0.8
150W	0.95	1.00
180W	1.04	1.10
200W	1.10	1.10
(6IK) 200W	1.00	1.10


LDS Small Gear Motor Ampere

Motor Power	Rated Ampere	F4.08 Setting
0.1kW	0.7	0.8
0.2kW	1.2	1.3
0.25kW	1.3	1.4

MAIN CONTROL CIRCUIT TERMINALS



TERMINAL AND WIRING



Note: The contents of this data sheet are subject to change without prior notice for the purpose of continuous product improvement. Comprehensive Product Manual of the Inverter available upon request.

IGBT Inverter's Error Message

Abnormality Diagnostic Function And Reset Method

Details and Remedies for various Fault Trips

Drive error trip message

Display	Description	Cause	Troubleshooting
<p>oc</p> 	<p>Drive over current</p> <ul style="list-style-type: none"> •The drive current during the operation exceeds 220% of drive's rated current. 	<ul style="list-style-type: none"> •The output terminals of drive are short. •The load is too heavy. •The acceleration time is too short. •Drive is immediately restarted during coast to stop. •Use special motor. 	<ul style="list-style-type: none"> •Check wires of U,V,W terminals to verify if there is short between terminals. •Check the motor and drive compatibility. •Check the motor operated in over-rated running.
<p>OL</p> 	<p>Motor overload</p> <ul style="list-style-type: none"> •Operation current exceeds 150% of motor's rated current and reaches the motor overload protection time. •Active time: F4.10. 	<ul style="list-style-type: none"> •Motor is overloaded. •The voltage setting of V/F pattern is too high or too low. •The current setting of motor's rated current is invalid. 	<ul style="list-style-type: none"> •Check the load of motor. •Check if the acceleration or deceleration time is too short. •Check if V/F setting is proper. •Check if the rated current setting is valid.
<p>OL1</p> 	<p>Drive overload</p> <ul style="list-style-type: none"> •Operation current exceeds 150% of drive's rated current and continues for 1minute. 	<ul style="list-style-type: none"> •Motor overload. •The voltage setting of V/F pattern is too high or too low. •Drive capacity is too small. 	<ul style="list-style-type: none"> •Check the load of motor if overload. •Check if the acceleration or deceleration time is too short. •Check if V/F setting is proper. •Select the higher capacity of drive.
<p>OLO</p> 	<p>System overload</p> <ul style="list-style-type: none"> •Load is too heavy and the operation current reaches the active level. •Detection level: F4.28 •Detection time: F4.29 	<p>---</p>	<p>Check the usage of mechanical equipment.</p>
<p>OE</p> 	<p>Over voltage</p> <ul style="list-style-type: none"> •The internal DC bus voltage is over the protection level. •100V/200V series: About DC410V •400V series: About DC820V 	<p>The deceleration time of motor is too short causing the regeneration voltage too high on DC bus.</p>	<ul style="list-style-type: none"> •Increase the setting value of deceleration time •Use high torque braking method. •Add dynamic brake unit to reduce regenerate voltage.
		<p>Power source is too high.</p>	<p>Check if the input power is within drive's rated range.</p>

Display	Description	Cause	Troubleshooting
LE1 	Under voltage during operation The internal DC bus voltage is below 70% of power source for 200V/400V series drive or 50% of power source for 100V series drive.	<ul style="list-style-type: none"> Phase failure of input power. Instantaneous power off. Voltage variation of power source is too high. Motor with instant overload causes the high voltage drop. 	Increase the power capacity by selecting higher capacity drive to avoid the voltage drop of the power cord.
ntcF 	Thermal sensor fault	Drive thermal sensor (NTC) is fault.	Please call customer service for drive repair.
OH 	Drive overheat <ul style="list-style-type: none"> The temperature of drive's heat sink reaches the trip level. Trip level: F4.12 	<ul style="list-style-type: none"> The surrounding temperature is too high. The heat sink has foreign body. The cooling fan of drive is fault. 	<ul style="list-style-type: none"> Improve the ventilation. Clean the dust on the heat sink. Return the drive to replace the cooling fan.

Display	Description	Cause	Troubleshooting
OH2 	Motor overheat <ul style="list-style-type: none"> The internal temperature of motor is over the trip level. Trip level: F4.23 	Motor is overheat.	<ul style="list-style-type: none"> Check if the motor load is too heavy. Check if the accel./decel. time is too short. Check if V/F setting is proper.
EF 	External fault	The multi-function terminal receives the external fault signal.	Clear the external fault and then press "STOP/RESET" key.
PAdF 	Keypad interruption during copy	<ul style="list-style-type: none"> The connecting wire of the keypad is loosen. The keypad jack of the drive is oxidized. 	Check the connecting wire of keypad.
EEr 	EEPROM error	<ul style="list-style-type: none"> EEPROM data write fault. EEPROM component defected. 	<ul style="list-style-type: none"> Please reset all parameters to default value and restart the drive. Return the drive to repair, when the fault cannot be eliminated.
EE1 	Internal memory error	CPU RAM is malfunction.	Please call customer service for drive repair.
EE2 	Internal memory error	The software checksum is incorrect.	Please call customer service for drive repair.

Drive warning message

*Drive will stop output when displaying below messages. After the fault conditions are troubleshooted, the drive will recover to normal condition.

Display	Description	Cause	Troubleshooting
<p>OLO</p> 	<p>System overload</p> <ul style="list-style-type: none"> ●Load is too heavy and the operation current reaches the active level. ●Detection level: F4.28 ●Detection time: F4.29 	---	Check the usage of mechanical equipment.
<p>Hv</p> 	<p>Power source over voltage</p> <p>The internal DC bus voltage of drive is over the protection level during stop.</p>	Power source voltage is too high.	Check if the input power is within drive's rated range.
<p>db</p> 	<p>Over voltage detection during deceleration</p> <ul style="list-style-type: none"> ●The internal DC bus voltage of drive is over the protection level. ●Setting level:F3.27 	The deceleration time of motor is too short causing the regenerate voltage too high on DC bus.	<ul style="list-style-type: none"> ●Increase the setting value of "deceleration time". ●Use high torque braking method. ●Add dynamic brake unit to reduce regenerate voltage
<p>LE</p> 	<p>Power source under voltage</p>	The voltage of power source is too low.	Check if the voltage of power source is normal.
<p>OHT</p> 	<p>Drive overheat</p> <ul style="list-style-type: none"> ●The temperature of drive's heat sink reaches the protection level. ●Setting level: F4.14 	<ul style="list-style-type: none"> ●The surrounding temperature is too high. ●The heat sink has foreign body. ●The cooling fan of drive is fault. 	<ul style="list-style-type: none"> ●Improve the ventilation. ●Clean the dust on the heat sink. ●Return the drive to replace the cooling fan.
<p>OH1</p> 	<p>Motor overheat</p> <ul style="list-style-type: none"> ●The internal temperature of motor is over the warning level. ●Warning level: F4.21 	Motor is over heat.	<ul style="list-style-type: none"> ●Check if the motor load is too heavy. ●Check if the accel./decel. time is too short. ●Check if V/F setting is proper.

Drive warning message

Display	Description	Cause	Troubleshooting
<p>bb</p>	Drive output interruption	Drive stops the output when the output interruption command is activated.	Clear drive output interruption command.
<p>Fr</p>	Coast to stop	Drive stops the output when the coast to stop command is activated.	Clear "coast to stop" command.
<p>dtF</p>	Forwad/reverse command input simultaneously	Input the forward/reverse command to one of X1~X4 terminals simultaneously.	Check the control command.
<p>Inter-display with frequency command</p>	No input of forward/reverse command	---	Check rotation direction command.
<p>WrF</p>	Different software version inter-copy	The software version of drives is different.	Check up the software version is corresponded.
<p>Cot</p>	Modbus communication overtime	<ul style="list-style-type: none"> •Communication wire is loosen or connecting wire is incorrect. •Communication setting of host and receiver are different. 	<ul style="list-style-type: none"> •Check the wiring of communication wire. •Check the communication setting.
<p>Err 00</p> <p>Err 01</p>	<p>Err 00: Keypad cable trip before connecting.</p> <p>Err 01: Keypad cable trip during operation.</p>	<ul style="list-style-type: none"> •The connecting wire of the keypad is loosen. •The keypad jack of the drive is oxidized. 	Check the wire between the keypad and drive.

How to **Un-LOCK** your inverter before you can make change to the parameter **F0.01 set to [0]**



Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [<<] to shift digit of parameter : [F0.00]
3	Press tekan		Press [Δ] to parameter : [F0.01] Parameter Lock (Refer to Page 16)
4	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [1] – Parameters are locked
5	Press tekan		Press [∇] to new command : [0] Parameter are changeable Refer to page 16
6	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

8B)



How to **LOCK** your inverter after you have done the chances to the parameter. **F0.01 set to [1]**



Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [<<] to shift digit of parameter : [F0.00]
3	Press tekan		Press [Δ] to parameter : [F0.01] Parameter Lock (Refer to Page 16)
4	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [0] – Parameters are changeable
5	Press tekan		Press [Δ] to new command [1] Parameter are locked Refer to page 16
6	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

9) Switching Method between Various Mode of IGBT Inverter

★ Please **Un-LOCK** your inverter 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan 		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan 		Press [Δ] to display Operation Status [F1.00] Operation Parameter
3	Press tekan 		Press [Δ] to display Operation Status [F2.00] Frequency Parameter
4	Press tekan 		Press [Δ] to display Operation Status [F3.00] Control Parameter
5	Press tekan 		Press [Δ] to display Operation Status [F4.07] Protection Parameter
6	Press tekan 		Press [Δ] to display Operation Status [F5.19] Multi-Function Parameter
7	Press tekan 		Press [Δ] to display Operation Status [F6.55] Special Parameter
8	Press tekan 		Press [Δ] to display [F0.00] System Parameter Return to Step 1
END	Press tekan 		Press [PROG] to return to Initial Display Screen

10)
How to display current ampere of the running motor



User to has connect the inverter to the motor, and run the motor in order to measure current ampere.

***Refer to Step 6 – Display 5 Output Current**


★ Please **Un-LOCK your inverter** 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [RUN] to start running the motor. Main Display show [50.00] Display 1 Output Frequency at 50.00Hz
2	Press tekan		Press [FUNC/DATA] to show [50.00] Display 2 Frequency Command
3	Press tekan		Press [FUNC/DATA] to show [50.00] Display 3 Output Voltage
4	Press tekan		Press [FUNC/DATA] to show [343.3] Display 4 DC Bus Voltage
5	Press tekan		Press [FUNC/DATA] to show [0.7] Display 5 (0.7A) Output Current (Ampere) Ampere may varies according to Motor Load
6	Press tekan		Press [FUNC/DATA] to show [---.1] Display 6 Terminal Status (X1/X2/X3/Y1)
7	Press tekan		Press [FUNC/DATA] to show [28.1] Display 7 Temperature of Heat Sink
8	Press tekan		Press [FUNC/DATA] to show [1000] Display 8 Machine Speed (F1.13*50Hz)
END	Press tekan		Press [PROG] to return to Initial Display Screen

TERMINAL STATUS



Multi-function Input Terminal "X1" is active



Multi-function Input Terminal "X2" is active



Multi-function Input Terminal "X3" is active



Multi-function Output Terminal "Y1" is active

11A)
How to adjust the running frequency via KNOB on operation panel.

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Rotate <i>pusing</i>		Rotate [KNOB] to intended speed E.g. 40Hz
2	Press <i>tekan</i>		Press [RUN] to start running the motor. Main Display show [40.00] Display 1 Output Frequency

11B)
How to adjust the running frequency via UP/DOWN button on operation panel.

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press <i>tekan</i>		Press [UP/DOWN] to intended speed E.g. 30Hz
2	Press <i>tekan</i>		Press [RUN] to start running the motor. Main Display show [30.00] Display 1 Output Frequency at 30.00Hz

11C)
How to stop the running operation.

Step	Action	Screen Display (after action)	Remark
			When the inverter is in running mode. E.g. Running at 30Hz
1	Press <i>tekan</i>		Press [STOP/RESET] to stop the operation

Please **Un-LOCK** your **inverter** 1st before you can make any changes to other parameter (See Pg. 8)

12)

How to enable to knob function
(i.e. to adjust speed via Knob
rotation)

 Please **Un-LOCK** your
inverter 1st before you can
make any changes to other
parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan 		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan 		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan 		Press [<<] to shift digit of Parameter : [F1.00]
4	Press tekan 		Press [Δ] to parameter [F1.01] Primary Frequency Command (Refer to Page 17)
5	Press tekan 		Press [FUNC/DATA] to enter Parameter F1.08 Default Setting [1]
6	Press tekan 		Press [FUNC/DATA] to complete the new parameter change.
7	Press tekan 		Press [Δ] to parameter [F1.03] Display Mode 6 (Refer to Page 18)
8	Press tekan 		Press [FUNC/DATA] to enter Parameter F1.09 Default Setting [0]
9	Press tekan 		Press [Δ] to new command [2] VI – “Pot Knob” (Refer to page 38)
10	Press tekan 		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan 		Press [PROG] to return to Initial Display Screen

13)
How to set Maximum and Minimum Output Frequency
F2.32 set to [70.0]
F2.48 set to [0.30]

E.G - 1
 Maximum Output Frequency
 To 70Hz

Minimum Output Frequency
 To 21Hz
 *(0.30 multiplier of Maximum
 Output Frequency above)

E.G - 1
 Maximum Output Frequency
 To 60Hz

Minimum Output Frequency
 To 30Hz
 *(0.50 multiplier of Maximum
 Output Frequency above)

★ Please **Un-LOCK your inverter 1st** before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F2.00] Frequency Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F2.00]
4	Press tekan		Press [Δ] to parameter [F2.32] Maximum Output Frequency (Refer to Page 22)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F2.32 Default Setting [60.0]
6	Press tekan		Press [<<] to shift digit of frequency command : [60.0] 60.0Hz
7	Press tekan		Press [Δ] to new command [70.0] Max Speed at 70.0Hz Refer to page 22
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [Δ] to parameter [F2.48] Minimum Output Frequency (Refer to Page 22)
10	Press tekan		Press [FUNC/DATA] to enter Parameter F2.48 Default Setting [0.00]
11	Press tekan		Press [<<] to shift digit of frequency command : [0.00] 0.00 Multiplier
12	Press tekan		Press [Δ] to new command [0.30] 0.30 * Maximum Output Frequency (=21Hz)
13	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

14)
How to adjust Acceleration Time and Deceleration Time

F2.18 set to [3.0]
F2.19 set to [4.0]

E.g.
 Acceleration Time to 3.0second

Deceleration Time to 4.0second

★ Please **Un-LOCK** your inverter 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F2.00] Frequency Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F2.00]
4	Press tekan		Press [Δ] to parameter [F2.18] Primary Acceleration Time (Refer to Page 20)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F2.18 Default Setting [2.0]
6	Press tekan		Press [<<] to shift digit of frequency command : [2.0] 2.0Seconds
7	Press tekan		Press [Δ] to new command [3.0] 3.0Seconds Acceleration Refer to page 20
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [Δ] to parameter [F2.19] Primary Deceleration Time (Refer to Page 21)
10	Press tekan		Press [FUNC/DATA] to enter Parameter F2.19 Default Setting [2.0]
11	Press tekan		Press [<<] to shift digit of frequency command : [2.0] 2.0Seconds
12	Press tekan		Press [Δ] to new command [4.0] 4.0Seconds Deceleration Refer to page 20
13	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

15)
How to change Forward rotation direction to Reverse rotation direction
F1.00 set to [4]

 Please **Un-LOCK** your inverter 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan 		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan 		Press [Δ] to parameter [F1.00] Operation Parameter
3	Press tekan 		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [3] Forward
4	Press tekan 		Press [Δ] to new command [4] Reverse (Refer to page 17)
5	Press tekan 		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan 		Press [PROG] to return to Initial Display Screen


16)
How to display Motor RPM
instead of Frequency on screen

For 4Pole Motor (1500rpm)
F1.08 set to [6]
F1.09 set to [2]
F1.12 set to [4P]

For 2Pole Motor (3000rpm)
F1.08 set to [6]
F1.09 set to [2]
F1.12 set to [2P]

For 6Pole Motor (1000rpm)
F1.08 set to [6]
F1.09 set to [2]
F1.12 set to [6P]

 Please **Un-LOCK your inverter** 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan 		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan 		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan 		Press [<<] to shift digit of Parameter : [F1.00]
4	Press tekan 		Press [Δ] to parameter [F1.08] Main Display Selection (Refer to Page 18)
5	Press tekan 		Press [FUNC/DATA] to enter Parameter F1.08 Default Setting [1]
6	Press tekan 		Press [Δ] to new command [6] Display Mode F1.09 (Refer to Page 18)
7	Press tekan 		Press [FUNC/DATA] to complete the new parameter change.
8	Press tekan 		Press [Δ] to parameter [F1.09] Display Mode 6 (Refer to Page 18)
9	Press tekan 		Press [FUNC/DATA] to enter Parameter F1.09 Default Setting [0]
10	Press tekan 		Press [Δ] to new command [2] Motor Rotation Speed (RPM) (Refer to page 18)
11	Press tekan 		Press [FUNC/DATA] to complete the new parameter change.
12	Press tekan 		Press [Δ] to parameter [F1.12] No. of Motor Poles (Refer to Page 18)
13	Press tekan 		Press [FUNC/DATA] to enter Parameter F1.12 Default Setting [4P]
14	Press tekan 		Press [Δ] to new command [2P / 4P / 6P] RPM Display Value (Refer to page 18)
15	Press tekan 		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan 		Press [PROG] to return to Initial Display Screen

17)
How to display Machine Speed instead of Frequency on screen

Machine Speed Ratio
= Machine Speed Ratio F1.13 x Output Frequency

E.G (1).
At rated speed 50Hz, in order to show value "500" in Main Display Screen:

Setting as below
F1.08 set to [6]
F1.09 set to [3]
F1.13 set to [10.00]
(Machine Speed = F1.13 * 50)
(Machine Speed = 10.00 * 50)

E.G (2).
At rated speed 50Hz, in order to show value "800" in Main Display Screen:

Setting as below
F1.08 set to [6]
F1.09 set to [3]
F1.13 set to [16.00]
(Machine Speed = F1.13 * 50)
(Machine Speed = 16.00 * 50)

E.G (3)
If you are using 4pole motor (1500rpm), and your max frequency range is 80Hz . Gear reduction ratio 15.

Formula as below:
 $F1.13 = (1500 * (80\text{hz} / 50\text{hz}))$
 $= 2400 / \text{Gear Ratio } 15$
 $= 160 / \text{Default } 50\text{Hz}$
 $= 3.2$

F1.08 set to [6]
F1.09 set to [3]
F1.13 set to [3.2]

E.G (4)
If you want to show max 200 at LED Display.

Formula as below:
 $F1.13 = 200 / \text{Default } 50\text{hz}$
 $= 4$

F1.08 set to [6]
F1.09 set to [3]
F1.13 set to [4]

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F1.00]
4	Press tekan		Press [Δ] to parameter [F1.08] Main Display Selection (Refer to Page 18)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F1.08 Default Setting [1]
6	Press tekan		Press [Δ] to new command [6] Display Mode F1.09 (Refer to Page 18)
7	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
8	Press tekan		Press [Δ] to parameter [F1.09] Display Mode 6 (Refer to Page 18)
9	Press tekan		Press [FUNC/DATA] to enter Parameter F1.09 Default Setting [0]
10	Press tekan		Press [Δ] to new command [3] Machine Speed (MPM) Refer to page 18
11	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
12	Press tekan		Press [Δ] to parameter [F1.13] No. of Motor Poles (Refer to Page 18)
13	Press tekan		Press [FUNC/DATA] to enter Parameter F1.13 Default Setting [20.00]
14	Press tekan		Press [<<] to shift digit of Command [20.00]
15	Press tekan		Press [∇] to new command [10.00] Machine Speed 10x (Refer to page 18)
16	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

Please **Un-LOCK** your inverter 1st before you can make any chances to other parameter (See Pg. 8)

18)
How to adjust Thermal Current Protection (TCP - overload protection for your drive/motor)
F4.08 set to [0.1 ~ 2.0] Ampere

* Default Ampere may varies based on inverter capacity.

For setting of rated ampere protection, please refer to the rated ampere on the name plate of the motor.

E.g. for 3ph230V voltage, 90W motor's rated ampere is 0.65A (ampere).

In this case, you may set this TCP value to 0.7A.

You may set the overload ampere with 5% higher than rated ampere, as above.

Thermal Current Protection will be activated when your motor is running over pre-set TCP value for 12Seconds.

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press PROG		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press ▲		Press [Δ] to parameter [F4.07] Protection Parameter
3	Press ◀		Press [<<] to shift digit of Parameter : [F4.07]
4	Press ▲		Press [Δ] to parameter [F4.08] Motor Rated Current (Refer to Page 26)
5	Press FUNC DATA		Press [FUNC/DATA] to enter Parameter F4.08 Default Setting [0.6] Ampere * Ampere may varies based on motor capacity
6	Press ▲		Press [Δ] to new command [0.8] Overload Protection at 0.8Ampere (Refer to page 25)
7	Press FUNC DATA		Press [FUNC/DATA] to complete the new parameter change.
END	Press PROG		Press [PROG] to return to Initial Display Screen

Please **Un-LOCK your inverter 1st** before you can make any chances to other parameter (See Pg. 8)

19)
How to change the Switching Frequency of the inverter (a.k.a PWM Carrier Frequency)

F1.21 set to (0 ~ 6)

Default Setting : 4

* The higher the value, the motor noise is lower

(User can adjust to higher value of Carrier Frequency to reduce acoustic noise of inverter)

F1.21 allows the tone of the magnetic noise from the motor to be changed by switching the PWM carrier frequency. This parameter is also effective in preventing the motor from resonating with its load machine or its fan cover.

* Reduce the carrier frequency to reduce electromagnetic noise, but the acoustic noise of the motor is increased. Vice versa.

P/S : Recommended Carrier Frequency value : 3

★ Please **Un-LOCK your inverter 1st** before you can make any chances to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F1.00]
4	Press tekan		Press [Δ] to parameter [F1.21] Switching Frequency (Refer to Page 19)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F1.21 Default Setting [3]
6	Press tekan		Press [Δ] to new command [4] Motor noise is lower. Refer to page 17
7	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen


20)
How to use external speed potentiometer (VR) to adjust running frequency

F1.01 set to [0]


F1.03 set to [5]

(VR – Variable Resistor a.k.a. Adjustable Knob)

Potentiometer Resistance :
 20K Ohm (20kΩ), 1/4W.



TERMINAL AND WIRING



★ Please **Un-LOCK your inverter 1st** before you can make any changes to other parameter (See Pg. 8)


Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F1.00]
4	Press tekan		Press [Δ] to parameter [F1.01] Primary Frequency Command Selection (Refer to Page 17)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F1.01 Default Setting [1]
6	Press tekan		Press [∇] to new command [0] Frequency Command by Analog Input Selection Refer to page 17
7	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
8	Press tekan		Press [Δ] to parameter [F1.03] Analog Input Selection (Refer to Page 17)
9	Press tekan		Press [FUNC/DATA] to enter Parameter F1.03 Default Setting [0]
10	Press tekan		Press [Δ] to new command [5] VI Refer to page 17
11	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

21)
How to use 2-way External Selector Switch for :
Run / Stop operation
*** [RUN] button will be disabled.**


F1.00 set to [0]
F5.19 set to [22]
F5.21 set to [0]

Connect a Selector Switch between Terminal X1 and Com

★ Please **Un-LOCK your inverter** 1st before you can make any changes to other parameter (See Pg. 8)




Contact Block 1N/O
 Wire to Terminal - X1




Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [3]
4	Press tekan		Press [∇] to new command [0] Start / Rev Command Refer to page 17
5	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
6	Press tekan		Press [Δ] to parameter [F5.19] Multi-Function Input Terminal X1 (Refer to Page 29)
7	Press tekan		Press [FUNC/DATA] to enter Parameter F5.19 Default Setting [22]
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [<<] to shift digit of Parameter : [F5.19]
10	Press tekan		Press [Δ] to parameter [F5.21] Multi-Function Input Terminal X3 (Refer to Page 29)
11	Press tekan		Press [FUNC/DATA] to enter Parameter F5.21 Default Setting [1]
12	Press tekan		Press [∇] to new command [0] Disable Refer to page 17
13	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen


TERMINAL AND WIRING



RUN OPERATION





STOP OPERATION




22)
**How to use 3-way External Selector Switch for :
 Reverse / Stop / Forward operation**
 * [RUN] button will be disabled.

F1.00 set to [0]
F5.19 set to [22]
F5.20 set to [23]
F5.21 set to [0]

★ Please **Un-LOCK your inverter 1st** before you can make any changes to other parameter (See Pg. 8)



TERMINAL AND WIRING



Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [3]
4	Press tekan		Press [∇] to new command [0] Start / Rev Command Refer to page 17
5	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
6	Press tekan		Press [Δ] to parameter [F5.19] Multi-Function Input Terminal X1 (Refer to Page 29)
7	Press tekan		Press [FUNC/DATA] to enter Parameter F5.19 Default Setting [22]
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [<<] to shift digit of Parameter : [F5.19]
10	Press tekan		Press [Δ] to parameter [F5.20] Multi-Function Input Terminal X2 (Refer to Page 29)
11	Press tekan		Press [FUNC/DATA] to enter Parameter F5.20 Default Setting [23]
12	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
13	Press tekan		Press [Δ] to parameter [F5.21] Multi-Function Input Terminal X3 (Refer to Page 29)
14	Press tekan		Press [FUNC/DATA] to enter Parameter F5.21 Default Setting [1]
15	Press tekan		Press [∇] to new command [0] Disable Refer to page 17
16	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

23)
How to start inverter run automatically when power is switch on


F1.00 set to [0]
F5.19 set to [22] - Forward
 * or F5.19 set to [23] for reverse direction
F5.21 set to [0]

Connect Wire between Terminal X1 and Com

NOTE :
This setting is NOT recommended.
We recommend user to wait for 3-4 seconds interval (after power is on), then only run the frequency (inverter))

★ Please **Un-LOCK** your inverter 1st before you can make any chances to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [3]
4	Press tekan		Press [∇] to new command [0] Start / Rev Command Refer to page 17
5	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
6	Press tekan		Press [Δ] to parameter [F5.19] Multi-Function Input Terminal X1 (Refer to Page 29)
7	Press tekan		Press [FUNC/DATA] to enter Parameter F5.19 Default Setting [22]
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [<<] to shift digit of Parameter : [F5.19]
10	Press tekan		Press [Δ] to parameter [F5.21] Multi-Function Input Terminal X3 (Refer to Page 29)
11	Press tekan		Press [FUNC/DATA] to enter Parameter F5.21 Default Setting [1]
12	Press tekan		Press [∇] to new command [0] Disable Refer to page 17
13	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen




24)
How to setup Emergency Stop Button :
Motor operation is stopped,
But inverter is still power on.
F1.00 set to [0]
F5.19 set to [22]
F5.21 set to [0]

Connect a Emergency Switch between Terminal X1 and Com


★ Please **Un-LOCK your inverter 1st** before you can make any chances to other parameter (See Pg. 8)




EMERGENCY STOP OPERATION (Press)




RESUME OPERATION (Release)



Contact Block 1N/O
 Wire to Terminal - X1




TERMINAL AND WIRING



How to setup Emergency Stop Button :
Inverter power is cut (off)
Motor operation is stopped.
***Live wire is connected via Contact Block.**
***Neutral wire is connected to L2 of the inverter**

Contact Block 1N/O
 Wire to Live (power supply)



Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Multi-Function Parameter
3	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [3]
4	Press tekan		Press [∇] to new command [0] Start / Rev Command Refer to page 17
5	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
6	Press tekan		Press [Δ] to parameter [F5.19] Multi-Function Input Terminal X1 (Refer to Page 29)
7	Press tekan		Press [FUNC/DATA] to enter Parameter F5.19 Default Setting [22]
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [<<] to shift digit of Parameter : [F5.19]
10	Press tekan		Press [Δ] to parameter [F5.21] Multi-Function Input Terminal X3 (Refer to Page 29)
11	Press tekan		Press [FUNC/DATA] to enter Parameter F5.21 Default Setting [1]
12	Press tekan		Press [∇] to new command [0] Disable Refer to page 17
13	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

25)
How to use Sensor Relay to stop operation by using Jog Speed Setting (Motor rotation is stopped in shorter time compared to Coast to Stop function)

F2.16 set to [0]

F2.19 set to [0.1]

F5.19 set to [1] or [-1]

Sensor Relay between Terminal X1 and Com

★ Please **Un-LOCK** your inverter 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F2.00] Frequency Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F2.00]
4	Press tekan		Press [Δ] to parameter [F2.16] Jog Speed (Refer to Page 20)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F2.16 Default Setting [6.00] Hertz
6	Press tekan		Press [<<] twice to shift digit of frequency command : [6.00]
7	Press tekan		Press [∇] to new command [0.00] JogSpeed at Zero Hertz Refer to page 20
8	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
9	Press tekan		Press [Δ] to parameter [F2.19] Primary Deceleration Time (Refer to Page 21)
10	Press tekan		Press [FUNC/DATA] to enter Parameter F2.19 Default Setting [2.0]
11	Press tekan		Press [∇] to new command [0.1] Deceleration time at 0.1second
12	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
13	Press tekan		Press [<<] to shift digit of frequency command : [F2.19] Frequency Parameter
14	Press tekan		Press [Δ] to parameter [F5.19] Multi-Function Input Terminal X1 (Refer to Page 29)
15	Press tekan		Press [FUNC/DATA] to enter Parameter F5.19 Default Setting [22]
16	Press tekan		Press [∇] to new command [1] Jog Speed Command Refer to page 29
17	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

CONTINUE NEXT PAGE
 SENSOR INFORMATION &
 WIRING DIAGRAM


TERMINAL AND WIRING

Model : Omron Photoelectric Sensor (Output Relay Type)
 Type : E3JK-TR11 (Through-Beam Type)
 *Emitter + Receiver
 Type : E3JK-DR11 (Diffuse Reflective Type)
 Sensor Voltage AC 24 ~ 240V
 Inverter Incoming Power Supply AC 240V




Sensing Method


Through-Beam Type
 *Emitter + Receiver






Retro-Reflective Type



Diffuse-Reflective Type



TERMINAL AND WIRING




TERMINAL AND WIRING



Sensor Model : Omron E3FA-DN12
 Voltage 10 ~ 30VDC
 Inverter Terminal Output 0~10VDC



Compact size and shape. Can be installed almost anywhere.



Visible LED light for easy alignment.



27)
How to use run Forward and Reverse direction with different speed.

E.G
Forward at 40Hz
Reverse at 30Hz

- F0.18 set to [1]**
- F1.00 set to [0]**
- F2.00 set to [40]**
- F2.01 set to [30]**
- F5.19 set to [22]**
- F5.20 set to [23]**
- F5.21 set to [3]**

 **Please Un-LOCK your inverter 1st before you can make any changes to other parameter (See Pg. 8)**

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [<<] to shift digit of parameter : [F0.00]
3	Press tekan		Press [Δ] to parameter : [F0.18] Show Complete Parameter (Refer to Page 16)
4	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [0] – Simple Parameter
5	Press tekan		Press [Δ] to new command : [1] Complete Parameter Refer to page 16
6	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
7	Press tekan		Press [<<] to shift digit of parameter : [F0.01]
8	Press tekan		Press [Δ] to parameter [F1.00] Operation Parameter
9	Press tekan		Press [FUNC/DATA] to enter Parameter F1.00 Default Setting [3]
10	Press tekan		Press [∇] to new command [0] Forward or Reverse Command - Refer to page 17
11	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
12	Press tekan		Press [Δ] to parameter [F2.00] Frequency Parameter
13	Press tekan		Press [FUNC/DATA] to enter Parameter F2.00 Default Setting [50.00]
14	Press tekan		Press [<<] to shift digit of frequency command : [50.00]
15	Press tekan		Press [∇] to new command [40.00] Forward @ 40Hz Refer to page 20
16	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
CONTINUE NEXT PAGE			

CONTINUE NEXT PAGE
SENSOR INFORMATION & WIRING DIAGRAM



27 - Continued

How to use run Forward and Reverse direction with different speed.


**E.G : Forward at 40Hz
Reverse at 30Hz**

- F0.18 set to [1]**
- F1.00 set to [0]**
- F2.00 set to [40]**
- F2.01 set to [30]**
- F5.19 set to [22]**
- F5.20 set to [23]**
- F5.21 set to [3]**

★ Please **Un-LOCK your inverter 1st** before you can make any changes to other parameter (See Pg. 8)



TERMINAL AND WIRING



Step	Action	Screen Display (after action)	Remark
17	Press tekan	F2.00	Press [<<] to shift digit of Parameter : [F2.00]
18	Press tekan	F2.01	Press [Δ] to parameter [F2.01] Preset Speed 2 (Refer to Page 20)
19	Press tekan	10.00	Press [FUNC/DATA] to enter Parameter F2.01 Default Setting [10.00]
20	Press tekan	10.00	Press [<<] to shift digit of frequency command : [10.00]
21	Press tekan	30.00	Press [Δ] to new command [30.00] Reverse @ 30Hz Refer to page 20
22	Press tekan	F2.01	Press [FUNC/DATA] to complete the new parameter change.
23	Press tekan	F2.01	Press [<<] to shift digit of parameter : [F2.01]
24	Press tekan	F5.19	Press [Δ] to parameter [F5.19] Multi-Function Input Terminal X1 (Refer to Page 29)
25	Press tekan	22	Press [FUNC/DATA] to enter Parameter F5.19 Default Setting [22]
26	Press tekan	F5.19	Press [FUNC/DATA] to complete the new parameter change.
27	Press tekan	F5.19	Press [<<] to shift digit of Parameter : [F5.19]
28	Press tekan	F5.20	Press [Δ] to parameter [F5.20] Multi-Function Input Terminal X2 (Refer to Page 29)
29	Press tekan	10	Press [FUNC/DATA] to enter Parameter F5.20 Default Setting [10]
30	Press tekan	23	Press [Δ] to new command [23] Reverse Refer to page 17
31	Press tekan	F5.20	Press [FUNC/DATA] to complete the new parameter change.
32	Press tekan	F5.21	Press [Δ] to parameter [F5.21] Multi-Function Input Terminal X3 (Refer to Page 29)
33	Press tekan	24	Press [FUNC/DATA] to enter Parameter F5.21 Default Setting [24]
34	Press tekan	3	Press [∇] to new command [3] Multi Speed Level 1 Command (Refer to page 29)
35	Press tekan	F5.21	Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan	0.00	Press [PROG] to return to Initial Display Screen

29)
**How to duplicate parameter
 Between different inverter
 Via Remote Keypad.**

***Please use Ethernet Cable to
 connect the Keypad to the
 Inverter 1st before making this
 setting.**

28A)
**How to duplicate parameter
 from Inverter to Remote Keypad
 (Read)**

F0.20 set to [rdEE]



Portable Keypad
 With Modbus (RS485)
 Communication.

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [<<] to shift digit of parameter : [F0.00]
3	Press tekan		Press [Δ] to parameter : [F0.20] Default Setting (Refer to Page 16)
4	Press tekan		Press [FUNC/DATA] to enter Parameter F0.20 Default Setting [0] – Disabled
5	Press tekan		Press [Δ] to new command : [rdEE] Read/Copy the parameter from Inverter to Keypad (Refer to page 16)
6	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

28B)
**How to duplicate parameter
 from Remote Keypad to Inverter
 (Write)**

F0.20 set to [UrEE]



Please **Un-LOCK your
 inverter 1st** before you can
 make any chances to other
 parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [<<] to shift digit of parameter : [F0.00]
3	Press tekan		Press [Δ] to parameter : [F0.20] Default Setting (Refer to Page 16)
4	Press tekan		Press [FUNC/DATA] to enter Parameter F0.20 Default Setting [0] – Disabled
5	Press tekan		Press [Δ] to new command : [rdEE] Write/duplicate the parameter from Keypad to Inverter (Refer to page 16)
6	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

30)

How to use "SPEC" button on operation panel to run at 2nd Speed (Multi-speed Level 2 command)

E.g. Primary speed is at 40Hz (based on user control via KNOB). Secondary Speed to run at 25Hz.

F1.17 set to [4]
F2.02 set to [25.00]

In this case, when the motor is running at primary speed. User press and hold on "SPEC" button on operation panel, inverter speed will be running at 25.00Hz.

★ Please **Un-LOCK** your inverter 1st before you can make any changes to other parameter (See Pg. 8)

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [Δ] to parameter [F1.00] Operation Parameter
3	Press tekan		Press [<<] to shift digit of Parameter : [F1.00]
4	Press tekan		Press [Δ] to parameter [F1.17] SPEC Key Setting (Refer to Page 19)
5	Press tekan		Press [FUNC/DATA] to enter Parameter F1.17 Default Setting [0] Disable
6	Press tekan		Press [Δ] to new command [4] JogSpeed at Zero Hertz Refer to page 20
7	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
8	Press tekan		Press [<<] to shift digit of Parameter : [F1.17]
9	Press tekan		Press [Δ] to parameter [F2.00] Frequency Parameter (Refer to Page 20)
10	Press tekan		Press [<<] to shift digit of Parameter : [F2.00]
11	Press tekan		Press [Δ] to parameter [F2.02] Preset Speed 3 (Refer to Page 20)
12	Press tekan		Press [FUNC/DATA] to enter Parameter F2.02 Default Setting [20.00] Hz
13	Press tekan		Press [Δ] to shift digit of frequency command : [20.00] Hz
14	Press tekan		Press [Δ] to new command [25.00] Preset Speed 3 at 25Hz Refer to page 20
15	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

31)


How to give alarm signal to PLC via Relay

IGBT to give alarm signal to PLC via Relay,
when alarm signal is on, trigger one unit relay.

Com connect to power supply -24V

+24V connect to relay coil / Y1

TERMINAL AND WIRING



32)
How to restore parameter to original Factory Setting
(For Malaysia / Singapore / Thailand / Indonesia)
F0.20 set to [dF50]

★ Please **Un-LOCK your inverter** 1st before you can make any changes to other parameter (See Pg. 8)

After Factory Setting Reset/Restore, please amend the following parameter to the LDS Setting ★

Step	Action	Screen Display (after action)	Remark
			When Inverter is powered on. (Initial Screen Display)
1	Press tekan		Press [MODE] to display Operation Status [F0.00] System Parameter
2	Press tekan		Press [<<] to shift digit of parameter : [F0.00]
3	Press tekan		Press [Δ] to parameter : [F0.20] Default Setting (Refer to Page 16)
4	Press tekan		Press [FUNC/DATA] to enter Parameter F0.20 Default Setting [0] – Disabled
5	Press tekan		Press [Δ] to new command : [dF50] Default the factory setting of 50Hz Refer to page 16
6	Press tekan		Press [FUNC/DATA] to complete the new parameter change.
END	Press tekan		Press [PROG] to return to Initial Display Screen

LDS Compact Motor Ampere

Func-tion	Description	Initial Factory Setting (TW)	LDS Setting (MY-SG-TH) ★	Motor Power	Rated Ampere	F4.08 Setting
F0.01	Parameter Lock (Changeable/Lock)	0	0 (Un-Lock) 1 (Lock)	25W	0.23	0.3
F0.18	Parameter List (Simple/Complete)	0 (Simple)	1 (Complete)	40W	0.36	0.4
F0.20	Default Setting (Taiwan / Malaysia)	dF60	dF50	60W	0.50	0.6
F1.21	Switching Frequency	2	4	90W	0.65	0.7
F2.16	Jog Speed	6.0Hz	0.0Hz	120W	0.75	0.8
F2.18	Acceleration Time	5.0s	2.0s	150W	0.95	1.00
F2.19	Deceleration Time	5.0s	2.0s	180W	1.04	1.10
F2.32	Maximum Output Frequency	50.0Hz	60.0Hz	200W	1.10	1.10
F2.48	Minimum Output Frequency	0.0Hz	0.0Hz	(6IK) 200W	1.00	1.10
F4.07	Overload Protection (Independent)	1	2			
F4.08	Overload Protection Setting - Motor's Rated Ampere	0.3A ~ 1.5A Based on Motor Spec				
F4.10	OVLP Tripped Time	0.5 (30s)	0.5 (30s)			
F5.08	Analogue Frequency Dead Band	0.00	0.05			
F5.19	X1 Terminal	22	22 (Forward)	0.1kW	0.7	0.8
F5.20	X2 Terminal	23	23 (Reverse)	0.2kW	1.2	1.3
F5.21	X3 Terminal	10	1 (Jog Speed)	0.25kW	1.3	1.4
F5.25	Digital Response Time	10	3			

LDS Small Gear Motor Ampere

Motor Power	Rated Ampere	F4.08 Setting
0.1kW	0.7	0.8
0.2kW	1.2	1.3
0.25kW	1.3	1.4

33)

How to use Momentary Switch to adjust running frequency (Up/Down)

- F1.00 set to [0]
- F1.01 set to [4]
- F5.19 set to [22]
- F5.20 set to [14]
- F5.21 set to [15]
- F5.30 set to [1]
- F5.31 set to [10]
- F5.32 set to [2]

★ Please **Un-LOCK** your inverter
1st before you can make any chances
to other parameter (See Pg. 8)

Remark:

F5.30 : UP/DOWN Memory Selection (pg.30 or pg.70 of full manual)

F5.30 set to [0] : Erase UP/DOWN frequency command when power off

F5.30 set to [1] : **Store UP/DOWN frequency command when power off**

F5.31 UP/DOWN Frequency Calibration (pg.30 or pg.70 of full manual)

F5.31 set to [10] : **Frequency adjust by 1Hz per press on momentary switch (10 x base frequency 0.1Hz)**

F5.31 set to [20] : Frequency adjust by 2Hz per press on momentary switch (20 x base frequency 0.1Hz)

*Max is [250] : Frequency adjust by 25Hz per press on momentary switch (250 x base frequency 0.1Hz)

F5.32 UP/DOWN Calibration Time (pg.31 or pg.70 of full manual)




F5.32 set to [1] : Pressing momentary button for more than 1second to adjust frequency continuously.

F5.32 set to [2] : **Pressing momentary button for more than 2seconds to adjust frequency continuously.**

F5.32 set to [5] : Pressing momentary button for more than 5seconds to adjust frequency continuously.

F5.32 set to [6] : Edge Trigger - Pressing momentary button 1 time to adjust frequency continuously.

TERMINAL AND WIRING



34)

How to use Momentary Switch to adjust running frequency (Up/Down), and Momentary Switch to Clean Up/Down Frequency Command

* For this function, User need to press [RUN] button to start operation every time.

- F1.00 set to [1]
- F1.01 set to [4]
- F5.19 set to [14]
- F5.20 set to [15]
- F5.21 set to [16]
- F5.30 set to [0]
- F5.31 set to [10]
- F5.32 set to [2]

★ Please **Un-LOCK** your inverter 1st before you can make any chances to other parameter (See Pg. 8)

Remark:

F5.30 : UP/DOWN Memory Selection (pg.30 or pg.70 of full manual)

F5.30 set to [0] : Erase UP/DOWN frequency command when power off

F5.30 set to [1] : Store UP/DOWN frequency command when power off

F5.31 UP/DOWN Frequency Calibration (pg.30 or pg.70 of full manual)

F5.31 set to [10] : Frequency adjust by 1Hz per press on momentary switch (10 x base frequency 0.1Hz)

F5.31 set to [20] : Frequency adjust by 2Hz per press on momentary switch (20 x base frequency 0.1Hz)

*Max is [250] : Frequency adjust by 25Hz per press on momentary switch (250 x base frequency 0.1Hz)

F5.32 UP/DOWN Calibration Time (pg.31 or pg.70 of full manual)


F5.32 set to [1] : Pressing momentary button for more than 1second to adjust frequency continuously.

F5.32 set to [2] : **Pressing momentary button for more than 2seconds to adjust frequency continuously.**

F5.32 set to [5] : Pressing momentary button for more than 5seconds to adjust frequency continuously.


F5.32 set to [6] : Edge Trigger - Pressing momentary button 1 time to adjust frequency continuously.

TERMINAL AND WIRING




DIMENSION – COMPACT IGBT INVERTER

Compact Inverter with LED Digital Display



DIMENSION – PORTABLE KEYPAD



The keypad

- Enable remote control of the inverter via Modbus (RS485) Communication.
- Duplication of parameter from Inverter to Inverter.